
WOLFSON UNIT


FOR MARINE TECHNOLOGY AND INDUSTRIAL AERODYNAMICS

Freeboard Guidance.

What does it mean?


Wolfson Unit database collated for MCA in 2005 and used to develop the guidance on freeboards







The small vessel fleet


Decked vessels
+ Undecked vessels
Casualties
Proposed guidance, decked
Proposed guidance, undecked



Additional data collected by MCA in 2011 as an impact assessment of the proposed guidance














Freeboard Guidance Mark - size and location



Name Aleyna No. NN138 Owner Mr Lucky Length 14 metres Beam 4.9 metres	Loading & Lifting Guidance	Safety Zone	Minimum Freeboard	Maximum Recommended Seastate
	Good margin of residual freeboard	Good margin of safety	At least 55 cm	
	Loading or lifting reduces minimum freeboard to less than 55 cm	Low level of safety	27 to 55 cm	1.6 metres
	Excessive loading or lifting reduces minimum freeboard to less than 27 cm	Danger of capsize	Less than 27 cm	0.8 metres





Aleyna


Very low freeboard - Amber safety zone in normal operation when upright


No margin for lifting - Any significant lift reduced freeboard to Red danger zone

Freeboard Guidance refers to the *residual operational* freeboard





Heather Anne -Capsized in December 2011 while overloaded















Sarah Jayne – Capsized in September 2012 when overloaded and lifting






- Decked vessels
- Undecked vessels

These data mean very little without a knowledge of how the boats are operated and how much their freeboard is affected.

Freeboard guidance is most useful to the skipper and crew; **not** the administration.



Freeboard guidance gives meaningful information to the fishermen.

It should **not** give naval architects, insurers or regulators something to hide behind.

Why freeboard?

The most useful measure of vulnerability to capsize is range *Residual range*

The second most important parameter is righting moment **Residual righting moment**

Both are provided by freeboard

Residual freeboard

Why not GM?

High GM may provide a high righting moment

BUT

Often associated with wide beam:
low range,
low angle of maximum GZ,
low angle of deck edge immersion,
low resistance to capsize in waves

Many casualties had high values of GM


Normal operation, lifting gear


GM: good


Freeboard: good

Range: > 50 degrees

RMmax: 0.14








Vessel overloaded, lifting gear


GM: good


Freeboard: reduced

Range: 31 degrees

RMmax: 0.06







Vessel overloaded & heavy lift


GM: adequate


Freeboard: none


Range: 19 degrees

RMmax: 0.027









If you can maintain some freeboard You are probably safe

But you need to know how safe relative to the seastate

You need Freeboard Guidance

STABILITY NOTICE						
Name Aleyna No. NN138 Owner Mr Lucky Length 14 metres Beam 4.9 metres	Loading & Lifting Guidance	Safe:y Zone	Mintraum Freeboard	Maximum Recommended Seastate		
#	Goed margin of residual freeboard	Good margin of safety	At least 55 cm			
	Loading or litting reduces minimum froeboard to loss than 55 cm	Low level of safety	27 to 55 cm	1.0 motros		
41	Excessive leading or lifting recuess minimum freedourd to less than 27 cm	Danger of capsize	Less than 27 cm	0.6 metas		



WOLFSON UNIT

FOR MARINE TECHNOLOGY AND INDUSTRIAL AERODYNAMICS